



BROAD RIM TEA SAUCER
ZCA POS71 17.1cm 6¾"
 CTN QTY 6
 (Fits ZCA POM21)



ESPRESSO CUP
ZCA PEC31 8.5cl 3oz
 H: 5cm
 Dia: 7cm
 CTN QTY 6



SMALL SAUCER
ZCA POS51 12.7cm 5"
 CTN QTY 6
 (Fits ZCA PEC31)



ESPRESSO CUP
ZCA POEC1 7cl 2.5oz
 H: 5.5cm
 Dia: 6cm
 CTN QTY 6



BEVERAGE POT
ZCA POP11 42cl 15oz
 H: 12cm
 CTN QTY 4
REPLACEMENT LID
ZCA PL151
 CTN QTY 6



JUG
ZCA POJ51 14cl 5oz
 H: 8.5cm
 CTN QTY 4



JUG
ZCA POJ21 6cl 2oz
 H: 7cm
 CTN QTY 4



LIDDED SUGAR POT
ZCA POSB1 23cl 8oz
 H: 8cm
 CTN QTY 4
REPLACEMENT SUGAR BOWL LID
ZCA PLSB1
 CTN QTY 6



PRESENTATION PAN
ZCAPPA4 1 11.8cm 4¼"
 23cl 8oz
 CTN QTY 6



LIDDED CASSEROLE
ZCAPMC251 17cm 6¾"
 77cl 27oz
 CTN QTY 6



LIDDED CASSEROLE
ZCAPMC121 13.4cm 5¾"
 37cl 13oz
 CTN QTY 6



REPLACEMENT LIDS
ZCAPCL251 (Fits ZCAPMC251)
 CTN QTY 6
ZCAPCL121 (Fits ZCAPMC121)
 CTN QTY 6