



24. 74oz Round Kiln®
Ovenware Dish w/Lid
9.25 dia x 11.75 x 3.25, 74oz
Pack 2
DBO139BKC20
Replacement Lid
DLI139BKC20



25. 56oz Round Kiln®
Ovenware Dish w/Lid
9 dia x 11.25 x 3, 56oz
Pack 2
DBO140BKC20
Replacement Lid
DLI139BKC20



26. 21oz Round Kiln®
Ovenware Dish w/Lid
6.25 dia x 8 x 2.25, 21oz
Pack 4
DBO132BKC21
Replacement Lid
DLI132BKC21



NEW ITEM

27. 16oz Round Kiln®
Ovenware Dish w/Lid
4.75 dia x 6.25 x 2.25, 16oz
Pack 12
DBO133BKC23 black
DBO133ORC23 blood orange

Replacement Lid
DLI133BKC23 black
DLI133ORC23 blood orange



NEW ITEM

28. 7oz Round Kiln®
Ovenware Dish w/Lid
4 dia x 5.25 x 2, 7oz
Pack 12
DBO134BKC23 black
DBO134ORC23 blood orange

Replacement Lid
DLI134BKC23 black
DLI134ORC23 blood orange



NEW ITEM

29. 16oz Rectangle Kiln®
Ovenware Dish
7.75 x 4.25 x 2.25, 16oz
Pack 12
DBO137BKC23 black
DBO137ORC23 blood orange



NEW ITEM

30. 10oz Rectangle Kiln®
Ovenware Dish w/Lid
6.25 x 3.75 x 2, 10oz
Pack 12
DBO135BKC23 black
DBO135ORC23 blood orange

Replacement Lid
DLI135BKC23 black
DLI135ORC23 blood orange



NEW ITEM

31. 14oz Square Kiln®
Ovenware Dish
6.25 x 5.25 x 1.75, 14oz
Pack 12
DBO138BKC23 black
DBO138ORC23 blood orange



NEW ITEM

32. 8oz Square Kiln®
Ovenware Dish w/Lid
5.5 x 4 x 2, 8oz
Pack 12
DBO136BKC23 black
DBO136ORC23 blood orange

Replacement Lid
DLI136BKC23 black
DLI136ORC23 blood orange